

Rapidly Detect Pipeline Leaks with Cloud-Native SaaS SCADA that Offers Accurate Alarming

BACKGROUND

A leak detection system is a subset of the overall asset integrity management program for most oil and gas operators. Since pipelines are often in remote areas, a leak can go unrecognized for days. Leaks or spills can require costly remediation, often including removal and treatment of affected dirt. The potential for regulatory fines and lost production is significant.

While a leak detection system cannot eliminate leaks, it is an essential component of a pipeline asset management program and helps reduce the impact of such events through expedited detection and remedial action.



WHAT'S YOUR CHALLENGE?

Conventional remote monitoring methods include monitoring inflow and outflow volumes, pressure, flow, and pump status with alarms triggered when certain patterns exhibit behaviors outside of preset thresholds.

Traditional leak detection methods involve regular intervals of inspection using tactics such as pigging, sniffer dogs, and visual inspection. These are sometimes enhanced by continuous monitoring methods based on external systems such as fiber optic and acoustic monitoring. Continuous monitoring can also be accomplished through internal, computational-based methods such as rate-transient or mass-balance analysis. While these conventional methods are common, they tend to be more complex and require constant maintenance. Buildup of sediment and other particulates at the turbine meter can also cause erroneous readings.

But not every anomaly indicates a leak, or even an actionable situation. "Alarm fatigue" (excessive alarming) can lead to field personnel being unable to distinguish real situations from false alarms, leading to delays in identifying leaks.

Pipeline operators need an intelligent system that separates alarm-worthy incidents from non-emergency anomalies.

What if you could...

- Detect small leaks, as small as <1% of total flow within 30 minutes?
- Rely on a solution with fewer false alarms, allowing quick dispatch of repair teams?
- Distill pipeline monitoring data into useful, easy-to-read charts and dashboards?

WHAT'S YOUR OPPORTUNITY?

DeltaV SaaS SCADA with Pipeline Protect utilizes pipeline pressures, flow rates, and pump status to analyze flow patterns and determine if an issue is present. It is based on statistical approaches, such as Sequential Probability Ratio Testing (SPRT), that are widely considered among the most reliable in the industry. Our approach characterizes and distinguishes between the “normal” and “abnormal” operation of the asset, including transient behaviors. This approach avoids many of the problems that are present with other computational-based methods and offers a more robust, timely, and hands-off process as compared to external systems and visual monitoring. Instead of modeling the pipeline in mathematical terms, which can be complicated, our approach is to observe the overall behavior of the pipeline and characterize it from the statistical perspective to determine the data patterns that are normal and abnormal.

Optimized for single phase, incompressible fluids, the system uses data from existing sensors to learn the normal operating parameters and diagnose when a potential incident is occurring, including system anomalies and other maintenance issues. Using historical and live data, the system can improve accuracy as the software tracks pump outages, meter reliability metrics, and changes in pressure and flow.

***DeltaV SaaS SCADA
with Pipeline Protect reduces risk
to ensure a high-performing asset
integrity management program.***

As part of a leak detection program, our software does not and cannot eliminate leaks. Early detection and intervention, however, can potentially reduce the impact of leaks.



Figure 1. Cloud-based data access enables remote control and optimization of oil and gas operations and assets in remotely located locations.

INTELLIGENT PIPELINE PROTECTION

Suitable for well sites, mains without redundancy, critical feeder mains, mains with a history of rupture or leaks, and some industrial supply lines, the system detects a wide range of anomalies, including leaks. It is applicable for pipeline fluids that are single-phase and incompressible, including water or oil. Our solution provides a range of benefits, including:

- Detection of small leaks; as low as <1% of total flow for certain pipeline configurations
- Expedited detection time; within 20 to 30 minutes in most cases
- Reduction of response time can be as much as 2 hours on average, when combined with a SCADA system
- Resilience to erroneous readings due to turbine meter buildup
- Detection of anomalies beyond just leaks: such as flow meter buildup, compressor issues, inlet separator water level problems, meter errors, and plant shutdowns

ADVANTAGES OF EMERSON'S SOLUTION

Flexibility

- Easily customize
- Compliments any existing SCADA
- Enables authorized users to instantly input and update current data
- Anywhere, anytime access

Data Visibility

- Vivid analytics
- Automated work-flows
- Continuous polling
- Data trending
- Custom reporting



Figure 2. Dashboard views of Pipeline Protect on DeltaV SaaS SCADA that is on the Maps tab.

Performance Opportunities

Intelligent Alarming

Trending and Reporting

Easy-to-Understand Dashboards

Remote Data Access

Secure, Cloud-based Platform

How Your Operations Will Benefit

Expedite analysis and response time to anomalous operating conditions. Reduce false alarms and wasted trips to field sites.

Data trending, default and custom reports to seamlessly provide clear analytics for regulatory and environmental reporting.

Clear, easy-to-understand data for the reports you choose. System displays operational status, flow, and pressure rates.

Anywhere anytime access with DeltaV SaaS SCADA Mobile.

Internal IT is not required. The platform includes evergreen updates, historian management, and full 24/7 support and all-inclusive training.

APPLICATION NOTE

DeltaV™ SaaS SCADA is an IIoT cloud-native platform designed to enable asset-intensive industries to quickly and securely connect, acquire analytics and provide control of remotely located devices anywhere, anytime by anyone of your authorized users. We help our customers become more productive, profitable and sustainable to improve life around the globe.



North America and Latin America Global Headquarters

Emerson Automation Solutions
6005 Rogerdale Road
Houston, TX, USA 77072
T: +1 281 879 2699



Europe

Emerson Automation Solutions
Unit 1, Waterfront Business Park
Dudley Road, Drierley Hill
Dudley, UK DY5 1LX
T: +44 1384 487200



Middle East and Africa

Emerson Automation Solutions
PO Box 17033
Jebel Ali Free Zone - South 2
Dubai, UAE
T: +971 4 8118100



Asia Pacific

Emerson Automation Solutions
1 Panda Crescent
Singapore 128461
T: +65 6777 8211

© 2024 Emerson. All rights reserved.

The Emerson logo is a trademark and service mark of Emerson Electric Co. All other marks are the property of their respective owners.

The contents of this publication are presented for information purposes only, and while every effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding the products or services described herein or their use or applicability. All sales are governed by our terms and conditions, which are available on request. We reserve the right to modify or improve the design or specifications of our products at any time without notice. Responsibility for proper selection, use and maintenance of any product remains solely with the purchaser and end user.

Find us in social media

Emerson | DeltaV Automation Platform

DeltaV SaaS SCADA

DELTA V™

For more information:
www.Emerson.com/DeltaVSaaS SCADA

EMERSON™